



Assembly Instructions – Elevated Basket Truck

Parts Included:

- Six (6) Push Nuts
- One (1) Push Nut Driver (approx. 4” hollow metal piece)
- One (1) Basket Truck
- One (1) Base with casters

Tools Needed:

- Hammer

Assembly Instructions:

1. Remove basket truck and base from shipping container.
2. Locate push nuts and push nut driver
3. Have your hammer available
4. Place basket truck upside down on ground
5. Position wood base (caster side up) over frame rod ends
6. Insert frame rods into holes on wood base
Frame rods will extend through wood base and caster plate
 - use hammer if necessary to tap base onto frame rods
7. Place push nut onto frame rod, raised side up
8. Place metal push nut driver over frame rod and push nut
9. Tap push nut driver with hammer
10. Repeat on other 5 rods.

Royal Basket Trucks customer service is available at 1-800-426-6447 or you can contact us at sales@royal-basket.com.